

Paint Effects

Limewashing

Limewash was historically a very dilute form of quicklime applied to walls as a protective or decorative coating. Nowadays we use modern paints to produce a similar effect by applying a translucent or thinned coat of paint over a basecoat. Limewash effects work well over a plastered or textured surface such as Resene Sandtex textured finish.



You will need:

- 100mm-125mm paintbrushes (2)
- Container for mixing glaze
- Mixing stick
- Resene Lumbersider tinted to Resene Orchid White and Resene Putty
- Resene Paint Effects Medium
- Soft cotton cloth

Method:

1. Apply two coats of the base colour Resene Orchid White and allow to thoroughly dry. If you wish to use a textured basecoat replace the second coat of the base colour with a coat of the desired textured finish tinted to the base colour.

Mix an effects finish of
3 parts Resene Paint Effects Medium
1 part Resene Putty
1 part water

Dip about 10mm of the brush into the effects finish, tap the brush on the side of the container to remove the excess and place a few dabs of colour about 40-50cm apart over the basecoat. Moving the brush quickly in all directions, blend the colours.



2. Use a dry brush to soften and blur the edges.

A cotton cloth may be used to dab off heavier areas of effects finish and to help soften or remove brushstrokes.

When the first coat has dried thoroughly, you may apply a second coat to strengthen the colour or use another shade of the same colour to add interest and depth.



Tips:

You can vary the proportion of paint to Paint Effects Medium - the more medium added, the more translucent and subtle the finish will be.

Leave some of the basecoat unbrushed or cover very lightly so that there is a variation of colour between the basecoat and the effects finish coat.

Before you start your project try out different combinations and practice your application method on a piece of card until you are happy with the result. Resene Paint Effects Medium is available in 55ml testpots from your Resene ColorShop or online from the Resene website.

See the Resene Paint Effects brochure for a range of paint effects samples or visit the Resene website for more Paint Effects ideas - www.resene.co.nz/homeown/use_colr/paint_effects.htm (NZ) or www.resene.com.au/homeown/use_colr/paint_effects.htm (AUST).

Resene Paint Effects brochures are available free from Resene ColorShops or order your copy online from www.resene.co.nz/comn/whtsnew/colrdr/order.htm (NZ) or www.resene.com.au/comn/whtsnew/colrdr/order.htm (AUST).

In New Zealand:

32-50 Vogel Street, Lower Hutt,
PO Box 38-242, Wellington Mail Centre
Call 0800 RESENE, visit www.resene.co.nz
or email us at advice@resene.co.nz

In Australia:

PO Box 785, Ashmore City, Queensland 4214
Call 1800 738 383, visit www.resene.com.au
or email us at advice@resene.com.au

Project by Janet Scard
Photography by Joseph Zou

Resene

the paint the professionals use