

Paint Effects

Distressing

A distressed paint finish is a quick way to fake age and add character to a piece and is especially suitable for rustic looking items and furniture.



You will need:

- 33mm brush
- Coarse wire wool
- Glaze - Resene Qristal Clear Poly-Flat or Resene Aquaclear satin
- Masking tape
- Paper towels
- Resene Lumbersider or Resene Zylone Spacecote tinted to Resene Chenin, Resene Dell and Resene Lusty
- Sandpaper 240 grit or finer
- Saucer
- Stencil
- Stencil brush
- Wood finishing or varnishing brush
- Wooden tray

Tips:

In this project only part of the stencil has been used and then flipped over so that the design is more balanced and fits into the side of the tray nicely. Single elements from a stencil may be used to create your own design or you may add in elements such as an extra leaf at each end and a motif in the centre to fill gaps as required. Try various combinations on paper and when you are pleased with the result, start on your tray.

If you are confident of the design you wish to achieve you can paint it freehand onto the tray rather than stenciling.

See the Resene Paint Effects brochure for a range of paint effects samples or visit the Resene website for more Paint Effects ideas - www.resene.co.nz/homeown/use_colr/paint_effects.htm (NZ) or www.resene.com.au/homeown/use_colr/paint_effects.htm (AUST).

Resene Paint Effects brochures are available free from Resene ColorShops or order your copy online from www.resene.co.nz/comn/whtsnew/colrldr/order.htm (NZ) or www.resene.com.au/comn/whtsnew/colrldr/order.htm (AUST).

Method:

1. Sand the tray lightly, remove dust and paint with one or two coats of Resene Lusty. Leave to thoroughly dry.

2. Apply one coat of Resene Chenin topcoat.

3. When the topcoat has lost its shine but before the paint hardens, start rubbing gently over the paintwork with the wire wool in the same direction as the brushstrokes. Rub until the basecoat starts to show through and you have achieved the desired distressed effect. Pay particular attention to the edges and corners where paint would have been worn off over time.

4. Put a small amount of each of the Resene Lusty and Resene Dell on a saucer.

5. Place the stencil into position and tape securely. Using the stencil brush, pick up a small amount of the Resene Lusty and pounce on the saucer to distribute the paint through the bristles. Remove the excess on a paper towel. The brush should be virtually dry.

6. In a pouncing action, apply the paint to the stencil. Do all the red areas first. Wipe the stencil clean and clean the brush by rubbing the paint off on a paper towel. Washing the brush leaves excess water in the bristles and thins the paint down causing it to bleed under the stencil.

Apply the Resene Dell in the same way.

7. Seal with one or two coats of Resene Qristal Clear Poly-Flat or Resene Aquaclear satin. The use of a flat or satin sealer suits the style of a distressed finish as a higher gloss finish tends to suggest the item is newer.



In New Zealand:

32-50 Vogel Street, Lower Hutt,
PO Box 38-242, Wellington Mail Centre
Call 0800 RESENE, visit www.resene.co.nz
or email us at advice@resene.co.nz

In Australia:

PO Box 785, Ashmore City, Queensland 4214
Call 1800 738 383, visit www.resene.com.au
or email us at advice@resene.com.au

Project by Janet Scard
Photography by Joseph Zou

Resene

the paint the professionals use