



Mark Rayner shows you how to turn an old plastic wheelbarrow into a stylish summer planter – perfect for potted colour or for growing salad greens.













YOU WILL NEED

Brush
Bucket of clean water
Clean cloth
Drill with 10mm drill bit
Garden hose with running water
Good-quality potting mix
Old plastic wheelbarrow
Paintbrush
Potted colour (we used white pelargoniums)
Resene Lumbersider tinted to Resene Chill Out
Resene Paint Prep and Housewash
Resene Waterborne Smooth Surface
Sealer
Sandpaper

STEP 1

Drill drainage holes in the bottom of the wheelbarrow.

STEP 2

Mix one part Resene Paint Prep and Housewash to three parts clean water.

STEP 3

Use a brush to scrub the wheelbarrow clean using the diluted solution. Then rinse off with clean water and allow the wheelbarrow to dry.

STEP 4

Sand the sides, underneath and top edge of the wheelbarrow to "key" the surface, then wipe away any residue with a clean cloth.

STEP 5

Apply one coat of Resene Waterborne Smooth Surface Sealer to the sides, underneath and top edge of the wheelbarrow and allow two hours to dry.

STEP 6

Apply one coat of Resene Chill Out to the sides, underneath and top edge of the wheelbarrow and allow two hours to dry. Then apply a second coat, leaving to dry for another two hours.

STEP 7

Fill with good-quality potting mix and plant up with your favourite potted colour.

GET THE LOOK

Mark stained the deck with two coats of Resene Kwila Timber Stain.



For more on paints phone 0800 RESENE (0800 737 363) or visit your Resene ColorShop

or www.resene.co.nz