# **RECLAIMED STORAGE RACK**

ilin "ile D

DIY

Upcycle a pallet and old kitchen forks to help keep garden tools organised.

WORDS & PHOTOS MARK RAYNER



the paint the professionals us

## YOU WILL NEED

- Old wooden pallet (ours measured approx. 114cm x 114cm)
- Fence paling (ours was 1.2m long)
- Old kitchen forks
- Hammer
- Screwdriver
- Sandpaper (coarse)
- Stiff-bristled brush
- 50mm galvanised nails
- 25mm exterior timber screws
- 75mm exterior timber screws
- Paintbrush
- Heavy pliers or bench vice for bending forks
- Resene Lumbersider tinted to Resene Half Duck Egg Blue
- Resene Quick Dry



If the reclaimed pallet has previously been outside for any length of time it may be necessary to first treat it with Resene Moss & Mould Killer and then wash it with Resene Timber and Deck Wash prior to painting.









#### STEP ONE

Lightly sand the pallet to smooth any rough edges.

#### STEP TWO

Remove any sanding residue with a stiff-bristled brush.

#### STEP THREE

Apply one coat of Resene Quick Dry to the pallet and allow two hours to dry.



#### **STEP FOUR**

Apply one coat of Resene Quick Dry to the fence paling and allow two hours to dry.

#### **STEP FIVE**

Apply two coats of Resene Half Duck Egg Blue to the pallet, allowing two hours for each coat to dry.

#### **STEP SIX**

Apply two coats of Resene Half Duck Egg Blue to the fence paling, allowing two hours for each coat to dry.



### TO GET THE LOOK Mark painted the shed walls with Resene Lumbersider tinted to Resene Unwind.

#### **STEP SEVEN**

Carefully bend forks into 'S' shapes, as shown, using pliers or a bench vice.

#### STEP EIGHT

Fix forks to front of pallet, as shown, to form hanging hooks. Partly sink in some 75mm screws for hanging smaller tools, such as trowels and hand forks.

#### STEP NINE

Using 50mm nails, attach the fence paling to the top of the pallet to form a shelf, as shown.

#### **STEP TEN**

Fix the pallet to the shed wall using 75mm screws drilled in from the top, sides and underneath. Ensure it is securely attached before hanging tools.

