Build SUN SHELTER



SUN SHELTER

Give your furry best friend a shaded and comfy outdoor nap spot.

WORDS & PHOTOS KLAUDIA KRUPA

YOU WILL NEED Materials

- 45mm x 45mm timber in the following lengths:
- 870mm (x 4) – 840mm (x 3)
- Canvas fabric cut to 930mm x 1500mm
- Pallet
- penetrating oil stain
- Waterproof dog bed
- Waterproof stick-on Velcro hook and loop strips (x 4)

Tools

- Drill
- Drop saw
- Pencil
- Tape measure

needed to suit your pallet (ours measured 1150mm x 930mm).

BROUGHT TO YOU BY



Step 1 Cut both ends of the four 720mm lengths of timber at 60 degrees (parallel cuts). Also cut off one end of the four 870mm lengths at 30 degrees.

Step 2 Using two 720mm lengths and two 870mm lengths, assemble and screw together one end frame, as shown. Repeat to create a second frame.

Step 3 Join the two frames together by attaching three 840mm lengths between them with screws.

Step 4 Place the frame over the pallet and screw all four legs to the base.

Step 5 Apply two coats of Resene Waterborne Woodsman penetrating oil stain to the frame, allowing each coat to dry.

Step 6 Attach the Velcro strips to the four corners of the frame as shown. Pull the canvas tight over the frame to ensure a good fit when it sticks to the exposed adhesive backing of the Velcro strips.

Step 7 Lay a waterproof dog bed on the base and you have a shaded and comfy spot that is sure to get your dog's tail wagging.

Here's another idea Extend the fabric down to the base on the two ends, add some colourful bunting and place a bean bag inside to create a summer reading nook/playhouse for the kids to enjoy.

For more on paints and stains, phone 0800 RESENE (0800 737 363) or visit your Resene ColorShop resene.co.nz/colorshops













98 KIWI GARDENER | FEBRUARY 2023 KIWI GARDENER | FEBRUARY 2023 99