

















**Step 5** Fill the screw holes on the planter part with the exterior wood filler. Once dry, sand for a nice clean finish. Give the planter and plaque a good dust down.

Step 6 Prime and paint with your Resene exterior paint of choice (always follow the instructions on the tin). It is much easier to paint each piece now before they are screwed together.

**Step 7** Screw the planter to the plaque from the back.

**Step 8** Position and mark out your house numbers, and attach as per the manufacturer's instructions.

Step 9 Pre-drill holes in each corner for the wall or fence fixings. Attach your plaque to your wall or fence. Fill with soil and compost and put in your favourite plants.



**Jane Horne** and partner Simon Bartholomew design and develop projects from their studio (plainandsimple.co.nz) in Christchurch, managing projects throughout the South Island.