

# Chalk it up

Mark Rayner comes up with a crafty double-banger, a storage and memo board.



## You will need:

- Garden tools
- Paintbrushes (including an artists' brush)
- Pencil and screwdriver
- Paint stirrer and sandpaper
- Panel of 22mm plywood (ours measured 600mm x 1200mm)
- Hanging brackets with screws
- Resene No 4 roller and paint tray
- Resene Quick Dry waterborne primer undercoat
- Resene Lumbersider tinted to Resene Sail and Resene Aviator
- Resene Write-on Wall Paint

**Top tip:** Always use whiteboard markers to write on the memo board and a whiteboard eraser or soft cloth to clean it.



For more on paints phone 0800 RESENE (0800 737 363) or visit [www.resene.co.nz](http://www.resene.co.nz)



1

Lightly sand the plywood panel and apply one coat of Resene Quick Dry, allowing two hours to dry.



2

Apply two coats of Resene Sail to the plywood panel, allowing two hours for each coat to dry.



3

Place the garden tools on the painted panel (in the position they will eventually hang) and trace around each tool with a pencil.



4

Use an artists brush to paint the tool shapes with Resene Aviator, as shown.



5

Continue until all the shapes are painted and allow to dry for two hours. Apply a second coat. Allow to dry for two hours.



6

Mix both parts of Resene Write-on Wall Paint, according to instructions, and stir with a paint stirrer. Leave to stand for five minutes.



7

Apply two coats of Resene Write-on Wall Paint using the paint roller, applying evenly and in one direction. Allow two hours for each coat to dry.



8

Screw the hanging brackets into position, as shown, and screw or nail the storage panel to shed or garage inside wall. Wait 48 hours before writing on the board.