Resene

Metallic bust

 $\star \star \star$ Difficulty level \star easy $\star \star$ moderate $\star \star \star$ challenging

Resene art with Mark Rayner - 75

You will need:

- Clean cloth
- Damp cloth
- Mannequin bust
- Paintbrush
- Resene Enamacryl Metallic tinted to Resene Spark
- Resene Lumbersider tinted to Resene Domino
- Resene paint stirrer
- Resene Waterborne Smooth Surface Sealer
- Sandpaper

and the second secon



Step one Wipe the mannequin bust clean with a damp cloth and leave to dry.



Step two Lightly sand the mannequin bust to 'key' the surface.



Step three Wipe off any sanding residue with a clean cloth.



Step four Apply one coat of Resene Waterborne Smooth Surface Sealer to the mannequin bust and allow two hours to dry.





To get the look:

Mark painted the background wall with **Resene SpaceCote Flat** tinted to Resene Milk Punch.



Other ideas:

For a subtle grey/ green metallic effect paint the mannequin bust with one coat of **Resene Raptor and** two coats of **Resene Magnetic.**

For more ideas and inspiration visit your local **Resene ColorShop or** www.resene.com/ colorshops.

Check out our special Artists' section online www.resene.com/artists.



Step five Apply one coat of Resene Domino to the mannequin bust and allow two hours to dry.

In Australia:



Step six Carefully stir the Resene Enamacryl with a paint stirrer.



ressional

Step seven Apply one coat of Resene Spark to the mannequin bust and allow two hours to dry.



Step eight Apply a second coat of Resene Spark to the mannequin bust. Again, allow two hours to dry.



In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz