# Resene Blue metallic cabinet



**Difficulty level** ★easy ★★moderate ★★★challenging

Fun with furniture with Mark Rayner - 7

#### You will need:

- MDF bedroom cabinet
- Paintbrush
- Paint stirrer
- Paint tray and roller
- Resene Aquaclear gloss
- Resene Enamacryl Metallic tinted to Resene Yeehaa
- Resene Lumbersider tinted to Resene **Optimist**
- Resene Ouick Dry
- Resene Sandtex Mediterranean effect
- Sandpaper



Step one Lightly sand the MDF cabinet to provide a 'key'.



Step two Apply one coat of Resene Quick Dry to the cabinet and allow two hours to dry.



Step three Apply one coat of Resene Sandtex to the cabinet, lightly stippling the paint to create surface texture. Allow to dry.



Step four Apply one coat of Resene Optimist to the cabinet and allow two hours to dry.



Step five Paint the inside of the cabinet with a second coat of Resene Optimist and allow two hours to dry.



Step six Stir the Resene Yeehaa using a flat wooden paint



Step seven Apply two coats of Resene Yeehaa to the outside of the cabinet, allowing two hours for each coat to dry.



Step eight Apply two coats of Resene Aquaclear gloss to the outside of the cabinet, allowing two hours for each coat to dry.

Transform a humble **MDF** bedroom cabinet into metallic masterpiece with a little bit of help from Resene.



## To get the look:

painted Mark the background wall and skirting with Resene SpaceCote Low Sheen tinted to Resene Alamo.



### Other ideas:

Try a sizzling red combination of Resene Adrenalin Junkie and Resene Old Brick.

For more ideas inspiration visit your local Resene ColorShop or www.resene.co.nz www.resene.com.au.

**Check out our special Artists** section online www.resene.co.nz/artists/ artists canvas.htm

www.resene.com.au/ artists/artists\_canvas.htm.