

# **Plant stand**



**Difficulty level** ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 29

## You will need:

- Damp cloth
- Drill with large drill bit
- Galvanised nails
- Hammer
- Paintbrush
- Pencil

- Piece of treated plywood
- **PVA** glue (exterior)
- Resene Lustacryl tinted to Resene Nirvana
- Resene Quick Dry
- Ruler
- Sandpaper
- Saw



#### Step one

Remove the old seat of the chair by knocking out with a hammer - take care not to damage the chair frame.



#### Step two

Strengthen the chair frame, if necessary, with galvanised nails. Any existing nails or screws that may rust should be removed and replaced galvanised stainless steel.



#### Step three

Measure and mark the piece of plywood to fit within the frame of the seat, as shown.



# sene



## Step four

Cut the plywood to size and smooth any rough edges with sandpaper.

B



#### Step five

Fix the plywood into position with PVA glue and galvanised nails and drill several drainage holes, as shown.



#### Step six

Sand the chair frame back to bare wood and wipe off any sanding residue with a damp cloth.



#### Step seven

Apply one coat of Resene Quick Dry and allow two hours to dry.



### Step eight

Apply two coats of Resene Nirvana, allowing two hours for each coat to dry.



Turn

tired

old



# To get the look:

Mark painted the raised bed with Resene Lumbersider tinted to Resene Woodstock.



## Other ideas:

Create a rich red effect by painting the chair with Resene Lustacryl tinted to Resene Pohutukawa.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz www.resene.com.au.

**Check out our special Artists** section online www.resene.co.nz/artists/ artists canvas.htm

www.resene.com.au/ artists/artists\_canvas.htm.

