Resene

Greenhouse shelves

 \star \star Difficulty level \star easy \star moderate \star \star challenging

Weekend DIY with Mark Rayner - 62

You will need:

- 1.8m fence palings (x2)
- 50mm exterior wood screws
- Paint stirrer
- Paintbrush
- Pencil

• Resene Waterborne Woodsman tinted to Resene Japanese Maple

- Sandpaper
- Saw
- Screwdriver
- Tape measure



Step one Measure and mark two 500mm lengths from each of the fence palings.



Step two Cut the lengths to size and smooth any rough edges with sandpaper.



Step three Attach one of the 500mm lengths to one of the 800mm lengths, as shown, fixing at the corner with 50mm screws.



Step four In the same way, fix the second 800mm length and another of the 500mm lengths to form a rectangular frame, as shown.



Step five Fit the first of the shelves, as shown, fixing through each side with 50mm screws.



Step six In the same way, fix the second of the shelves, as shown.



Step seven Carefully stir the Resene Waterborne Woodsman tinted to Resene Japanese Maple.



Step eight Apply two coats of Resene Waterborne Woodsman tinted to Resene Japanese Maple to the shelves, allowing two hours for each coat to dry. Create some extra storage in your greenhouse or shed with these easy to make shelves.



To get the look: Mark stained the background wall with Resene Waterborne Woodsman tinted to Resene Grey Green.



Other ideas: For a soft blue effect stain the shelves with Resene Waterborne Woodsman tinted to Resene Pickled Bluewood.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.

In Australia: Call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au



In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz