

Brighten up a corner of the garden with this easy-to-build bird bath.

### You will need:

- Large ceramic bowl filled with water
- Paint stirrers
- Paintbrush
- Resene Concrete Primer
- Resene Lumbersider tinted to Resene Eighth Stonewashed
- Resene Waterborne Smooth Surface Sealer
- Square concrete paver
- Tall rectangular planter (ours was coated concrete)



#### Step one

Carefully open and stir the Resene Waterborne Smooth Surface Sealer.



#### Step two

Apply one coat of the Resene Waterborne Smooth Surface Sealer to the planter and allow to dry. (Note: if the surface of the planter is shiny, then sand it first to 'key' the surface.)



#### Step three

Carefully open and stir the Resene Concrete Primer.



#### Step four

Apply one coat of Resene Concrete Primer to the paver and allow to dry.



#### Step five

Carefully open and stir the Resene Lumbersider tinted to Resene Eighth Stonewashed.



#### Step six

Apply two coats of Resene Lumbersider tinted to Resene Eighth Stonewashed to the planter, allowing two hours for each coat to dry.



#### Step seven

Apply two coats of Resene Lumbersider tinted to Resene Eighth Stonewashed to the paver, allowing two hours for each coat to dry.



#### Step eight

Place the paver on top of the planter and then place the large ceramic bowl filled with water on top of this.



To get the look: Mark painted the background shed wall with Resene Lumbersider tinted to Resene Pale Leaf.



#### Other ideas:

For a pale green effect paint the bird bath with Resene Lumbersider tinted to Resene Soft Mint.

For more ideas and inspiration visit your local Resene ColorShop or [www.resene.com/colorshops](http://www.resene.com/colorshops).

Check out more project ideas online [www.resene.com/projects](http://www.resene.com/projects).