Shelf esteem

Make a floating bedside ledge that tones into your colour scheme, with our step-by-step instructions.

YOU WILL NEED

MDF board 1200mm x 600mm x 9mm Pencil

Ruler

Jigsaw

Sandpaper

2 x 10cm brackets

9mm wood screws (if you can't get screws that are short enough, add some washers)*

Power drill

Resene SpaceCote Low Sheen paint Wall fixings*

*Instead of using wall fixings and 9mm screws, you can use screws that are long enough to go right through the wall-facing shelf and the bracket and into the wall. Use filler to hide the tops of the screws before you paint.

INSTRUCTIONS

- 1 On the MDF, draw an oval that's 40cm across at the narrowest diameter and 46cm across at the widest diameter. Rule a line through the centre, across the shorter diameter.
- **2** Carefully cut out the shapes using the jigsaw. You should have two halves of an oval.
- **3** Sand the edges so they are smooth and the straight edge is nice and even.
- **4** Attach the brackets to the back of the shelf base with the wood screws, so they're an even distance from each end of the shelf.
- **5** Attach the wall-facing part of the shelf to the bracket with more wood screws, so that it meets the shelf base.
- **6** You are ready to paint! Use Resene SpaceCote Low Sheen in your choice of colour. We used Resene Cinnamon.
- **7** Secure shelf to the wall with an appropriate fixing that's strong enough to hold your chosen objects. **9**













