



Window dressing



Resene Casal

Transform regular casement windows into elegant grid-style options that double as pretty shelving – perfect for those small, sun-loving plants.

YOU WILL NEED

- Measuring tape
- 2 lengths of unsealed pine timber cut to fit your window frame (in our case, 1225mm long x 90mm wide x 20mm deep)
- Resene Quick Dry undercoat
- Resene Lustacryl, tinted in a Resene shade that matches the existing paint colour of your frame (we used Resene Alabaster)
- Mini roller
- Paint tray
- Pots and vases in a range of shapes and styles to suit your shelf (we used old storage containers and vases)
- Resene testpots in your chosen shades (we used Resene Clover, Resene Moroccan Spice, Resene Pioneer Red, Resene Pirate Gold and Resene Wild West)
- Resene Aquapel & Terracotta Sealer
- Paintbrushes
- Pencil
- Drill
- 4 x brackets (choose ones that come with screws)

INSTRUCTIONS

- 1 Measure the width and depth of your window frame, and choose a thickness for the shelves that suits your window. Cut your timber to these dimensions.
- 2 Paint your shelf timber with a layer of Resene Quick Dry undercoat. Once dry, paint the shelf in Resene Lustacryl in your chosen Resene colour, using a mini roller. *Tip: Find some blocks to raise your timber so you can paint each surface easily.*
- 3 Seal your pots inside and out with Resene Aquapel & Terracotta Sealer. Once dry, topcoat using Resene testpots in your chosen Resene shades.
- 4 Place the first painted length of timber inside your window frame. Ask someone to hold it while you use a pencil to mark where the brackets connect with the window frame.
- 5 To attach the shelves, drill the screws into the window frame and timber through the holes in the brackets. Repeat this process with your second length of timber.
- 6 Fill your colourful pots with plants and have fun styling the finished shelves. 🌿

PHOTOGRAPHY MICHAEL MOORE STYLING SAVANNAH BETTI

