



STEP 1 Lightly sand the headboard and

STEP 2 Apply one coat of Resene

STEP 3 Apply two coats of Resene Astronaut to the headboard. Allow to dry.


STEP 4 Using a small paint roller, apply two coats of Resene Time Warp to the headboard. Allow to dry.

STEP 5 Use a 'stippling' (dabbing) technique to stencil the Dreamweaver

the paint the professionals use o8oo RESENE (737 363) www. resene.co.nz

these bright and colourful creations to delight even the youngest of littlies. circus co





STEP 2 Apply one coat of Resene Smooth Surface Sealer to the cot. Allow

damp cloth.

STEP 3 Paint the bars of Resene Black.

STEP 4 Paint the legs and curved upper ends with N Wild, and the curved lower ends and side struts with two coats of Resene

STEP 5 Using Resene Black, paint tiger stripes over the





Hi Jinx. Once dry, apply a

STEP 6 Apply one coat of Resene Quick Dry acrylic primer undercoat to the four lengths of dowel. Once dry (about 1 hour), apply









For a list of products used for this project, see 'Bedtime project' on www.littlies. co.nz under Littlies Activities/Resene. Most of the accessories used in this project are available from The Warehouse (www.thewarehouse.co.nz) 0800 422 274.