

Resene Limelock

cure and seal

Resene Limelock is a new preparatory coating used for the curing and sealing of cementitious substrates. It promotes cure by producing a water barrier, which unlike traditional curing membranes, may be overcoated with waterborne finishes at any stage.

Its ability to cure and seal the substrate eliminates the need to leave the plaster to cure for seven days before painting. When dark, heat absorbing topcoats are planned, it is still prudent to wait seven days before painting.

Resene Limelock traps free lime in the cementitious substrate protecting the paint finish against the appearance of unsightly lime staining, and providing a perfect base for subsequent Resene finishes.

exterior

Typical uses

- Cementitious surfaces, including concrete, render, stucco, and thin layer polymer modified plaster

Vehicle type	100% acrylic
Pigmentation	Titanium dioxide
Solvent	Water
Finish	Semi-transparent gloss
Colour	White
Dry time (minimum)	30 minutes at 18°C
Recoat time (minimum)	Dependent on final colour planned
Primer required	No
Theoretical coverage	Dependent on surface porosity – typically 5-8 sq. metres per litre
Usual no. of coats	1
Abrasion resistance	Very good
Chemical resistance	Good
Heat resistance	Thermoplastic
Solvent resistance	Good
Durability	Excellent
Thinning and clean up	Water
VOC	c. 74 grams per litre (see Resene VOC Summary)

Physical properties

Performance

Performance and limitations

1. Promotes early cure of fresh cementitious surfaces minimising downtime between the completion of plastering and commencement of painting.
2. White pigmentation increases the albedo of the system to retain moisture.
3. Seals in free lime to protect against the unwanted appearance of lime staining.
4. Good adhesion to fresh cementitious substrates.
5. Provides an excellent base for a wide range of Resene coatings.
6. An Environmental Choice approved product.

Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. Resene Limelock is designed to be overcoated.
3. Resene Limelock is considered to be part of the surface preparation process and should be applied as soon as possible over plaster systems to achieve maximum potential.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of product. If in doubt contact Resene.



Limelock cure and seal

Surface preparation

If Resene Limelock is applied immediately following plastering, no surface preparation is necessary. If the surface has been allowed to weather, some surface preparation may be required, as for old work.

Old work

Ensure surface is clean and free from all contaminants. Waterblasting is the preferred preparation over older weathered surfaces.

Surface rust stains may indicate a deeper problem of carbonation and re-bar corrosion. Contact Resene if surface rust is present.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply to spray plasters immediately after spraying. Apply to trowelled plasters immediately after final trowelling. Apply to poured concrete, including slabs, as soon as the surface water has evaporated or as soon as the boxing is removed.

Apply one coat of Resene Limelock over the fresh substrate by commercial grade knapsack sprayer, spray, long pile roller or brush and allow to dry.

Evenly coat all fresh cementitious surfaces to ensure uniform curing and that free lime cannot be transferred through weak points.

Precautions

When dark, heat-absorbing topcoats are planned, it is prudent to wait seven days before painting.

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 785, Ashmore City, Queensland 4214
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.