

# RECYCLED **DRINKS**

Mark Rayner shows drinks table from recycled materials.

### YOU WILL NEED

40mm galvanised nails

Clamp

Hammer

Old wooden stool

Pieces of recycled timber

Paintbrush

Pencil

PVA glue (exterior)

Resene Lumbersider tinted to Resene Sail

Resene Quick Dry

Ruler

Sandpaper

Saw

Screwdriver

Set square







#### STEP 1

reclaimed from old drawers, shelves and an surface. old crate.

#### STEP 2

Remove any old screws or nails from the Dismantle the wooden stool, remove the recycled timber. Our selection of wood is legs and lightly sand each one to prime the

#### STEP 3

Measure, mark and cut pieces of wood to form a rectangular frame for the table top. We use six lengths of wood for our construction, but four might be sufficient. Smooth any rough edges with sandpaper.



#### STEP 4

Assemble the pieces of wood to form the rectangular base, fixing with PVA glue and nails at each corner. Use a set square to ensure corners are at right angles. Our base measures approximately 430mm x 490mm.



#### STEP 5

Position pieces of timber across the wooden frame, as shown, to form the table top. Overlap at one edge by 25mm and fix with PVA glue and nails. Use a small offcut of wood to ensure pieces of wood are evenly spaced.



#### STEP 6

Fix the remaining pieces of timber into position, as shown, to complete the table top. Again, ensure the lengths of wood are evenly spaced, and overlap one edge by 25mm.



#### STEP 7

Measure, mark and cut the overhanging pieces of timber, ensuring there's still a 25mm overlap along both ends.



#### STEP 8

Smooth any rough edges with sandpaper.



#### STEP 9

Fix a leg to each corner using PVA glue and nails. Secure the leg with a clamp while nailing. Allow glue to dry.



#### **STEP 10**

Apply one coat of Resene Quick Dry to the table, allowing two hours to dry.



#### **STEP 11**

Apply two coats of Resene Sail to the table, allowing two hours for each coat to dry.

#### A DIFFERENT FINISH?

We used Resene Lumbersider, which has a low-sheen finish, but if you prefer a gloss finish try Resene Enamacryl. For a semigloss finish, use Resene Lustacryl.

## HERE'S ANOTHER COLOUR OPTION:

Create a similar table from treated timber and stain it with any colour from the Resene Woodsman range.



the paint the professionals use

For more on paints phone 0800 RESENE (0800 737 363) or visit your Resene ColourShop or **www.resene.co.nz**